

NO. 4 VANELESS WINDMILLS

PRICE LIST OF REPAIRS (Continued)

	No.	10-ft.	No.	12-ft.
Bushing for No. 16 Spider.....	98J	\$.05	98J	\$.05
Bushing for No. 36 Weight Bar.....	99J	.05	99J	.05
Swivel Rod with Swivel.....	104J	.40	104Y	.50
Key for No. 9.....	106J	.10	106Y	.10
Key for No. 15.....	107J	.10	107Y	.10
"S" Hook.....	108	.10	108	.10
Outside Corner Washer.....	109	.10	109	.10
Inside Corner Washer.....	109 1/2	.10	109 1/2	.10
Actuating Rod.....	111	.85	111	.85
Pull Out Lever.....	130	.50	130	.50
Storm Stay Blocks.....	161	.15	161	.15
Bed Plate (Wood Tower).....	411	1.10	411B	1.50
Square Bar.....	423	2.60	423B	4.50
Swivel Casting.....	460	.70	460B	.90
Grease Cup Complete, 3/4-in pipe thread.....	463	.40	463	.40
Pull Out Wire.....	467	.36	467	.36
Swivel Only for No. 104.....	502	.10	502	.10
Engine with Tower Fittings as shipped.....		18.00		24.75
Square Bar Pitman and Guide Casting as shipped.....		7.75		12.50
Bundle Folding Rods as shipped.....		7.45		15.65
Bundle Wheel Braces (2 bdls. on 12 ft.) as shipped.....		8.10		6.20
Bundle Horse Weight Bars as shipped.....		2.35		3.00
Bundle Wood Arms as shipped.....		4.05		7.55
Bundle Windmill Rod as shipped.....		1.30		1.35
Crate Sections as shipped.....		16.00		23.55

Windmill-Parts.com

940 597-7735

REPAIR PLATE FOR NO. 4, 10-FOOT VANELESS WINDMILL




Fig. 1149

REPAIR PLATE FOR NO. 4, 12-FOOT VANELESS WINDMILL




Fig. 1150

DEMPSTER NO. 4 VANELESS WOOD WINDMILLS

PRICE LIST OF REPAIRS

	No.	10-ft.	No.	12-ft.
Main Frame	01J	\$ 7.65	1YY	\$ 8.75
Clamp for Main Stem			1 1/2 YY	1.80
Arm Casting	6 1/2	.30	6 1/2 X	.35
Swivel Casting	7	.30	7	.30
Swivel Casting	8	.30	8	.30
Fan Hinge, right	8 1/2	.20	8 1/2 X	.25
Fan Hinge, left	08 1/2	.20	08 1/2 X	.25
Face Plate	9J	1.60	9Y	2.20
Eye Pump Pin	11	.10	11	.10
Large Spider	15J	2.70	15Y	3.00
Plate for Large Spider	15 1/2 J	.40	15 1/2 Y	.50
Small Spider	16J	.50	16Y	.70
Storm Stay (Wood Tower)	16	1.50	16U	2.00
Pump Connection	20A	.50	20A	.50
Splice Irons (pair)	21	.50	21 1/2	.80
Top Box (large)	21 1/2 J	.60	21 1/2 Y	.70
Wheel Weight	22	.60	22C	.80
Top Box (small)	23 1/2 J	.60	23 1/2 Y	.70
Sliding Box	24J	.40	24Y	.60
Top Clutch Box	25 1/2 J	.60	25 1/2 Y	.60
Bottom Clutch Box	26J	.50	26J	.50
Regulating Weight	29	1.40	29X	2.00
Wrist Pin	32JJ	.70	32YY	1.00
Left Slide Rod	L-33JJ	.55	R-33YY	.70
Right Slide Rod	R-33JJ	.55	R-33YY	.70
Main Shaft	34J	2.30	34Y	2.70
Shifting Rod	35J	.40	35Y	.60
Weight Bar	36JJ	1.20	36YY	1.35
Section Rod	37J	.25	37Y	.40
Roller	38JJ	.10	38JJ	.10
Bed Plate (2-post wood tower)	39	1.20		
Storm Stay (2-post wood tower)	40	1.00		
Lower Guide Casting	40P	.45	40R	.55
Pitman	51JJ	1.10	51YY	1.25
Bed Plate (Steel Tower)	57B	1.50	57C	1.70
Storm Stay (Steel Tower)	58BB	1.05	58 1/2 U	1.70
Horse Weight	58G	1.80	58G	1.80
Clip for No. 63	62	.05	62	.05
Staple for Wheel Weight	63	.20	63B	.20
Babbitt Box	64J	.40	64Y	.60
Upper Pitman Pin	66JJ	.50	66 1/2 Y	.60
Nut for Pitman Pin	68	.05	68	.05
Balance Weight Bar	71J	1.50	71Y	1.60
Wheel Arm	72J	.85	72Y	1.00
Short Wheel Rib	75J	.30	75Y	.40
Long Wheel Rib	76J	.40	76Y	.50
Wheel Slat	77J	.10	77Y	.15
Wheel Section	78J	3.00	78Y	3.75
Angle Iron	80JJ	.30	80 1/2 Y	.40
Wheel Brace	81 1/2 J	.60	81 1/2 Y	.90
Staple for No. 23 1/2 Y		.25	82Y	.30
Truss for Main Frame	83JJ	.20	083Y	.30
Truss Rod for No. 71			83 1/2 Y	.30
Guide Rod	84JJ	.15	84YY	.20
Eye Bolt for No. 130	85	.10	85	.10
Weight Box	86J	1.50	86J	1.50
Weight Box Lid	87J	1.00	87J	1.00
Cast Washer (small)	88JJ	.10	88JJ	.10
Cast Washer (large)			88YY	.10
Brace for Horse Weight Bar	90JJ	.40	90YY	.50
Main Frame Pipe			91 1/2 Y	6.00
Square Bar Guide Casting	93J	2.80	93Y	3.30
Square Bar Guide Clamp	94J	.30	94Y	.40
Square Bar Guide Cap	95J	.25	95J	.25
Square Bar Guide Brace	96J	.20	96Y	.30
Bushing for No. 81 1/2 Wheel Brace	97J	.05	97J	.05

Ordered 5-4-31