

Windmill-Parts.com
940 597-7735

REPAIRS


FOR

NO. 3

SINGLE

GEARED

MILL



PART NO.	NAME	8 Ft. No. 3	10 Ft. No. 3
S 1	Main frame	\$8.65	\$8.65
S 2	Walking beam bracket	.95	.95
S 3	Walking beam bracket	.95	.95
S 4	Walking beam	1.55	1.55
S 5	Pitman	.60	.60
S 6	Walking beam and piston coupler	.60	.60
S 7	Vane frame	1.85	1.85
S 8	Pinion	1.10	1.10
S 9	Gear wheel	3.10	3.10
S 10	Brake lever	.60	.60
S 11	Small sheave	.40	.40
S 12	Pulley holder	.60	.60
S 13	Large spider	1.70	1.70
S 14	Small spider	.75	.75
S 16	Gear cover	2.15	2.15
S 17	Box plate	.35	.35
S 18	Front box cap	1.60	1.60
S 19	Lower guide	.70	.70
S 20	Upright pipe for main frame	1.60	1.60
S 21	Swivel clamp	.30	.30
S 22	Lower half swivel	.85	.85
S 23	Upper half swivel	.55	.55
S 24	Spring lever	.60	.60
S 25	Vane frame bar	1.20	1.55
S 26	Pulley bar	.95	1.20
S 27	Spring	.90	1.00
S 28	Piston flat bar	1.00	1.00
S 29	Pull out chain	.45	.45
S 30	Vane pipe	2.00	2.50

PART NO.	NAME	8 Ft. No. 3	10 Ft. No. 3
S 31	Vane truss	.60	.75
S 32	Crank	3.70	2.70
S 33	Brake band	.60	.70
S 34	Main shaft	2.50	2.50
S 36	Wheel arm	.90	1.25
S 37	Pump to wood rod connection	.60	.60
S 38	Cast washer	.20	.20
S 39	Walking beam pin	.25	.25
S 40	Walking beam pin	.25	.25
S 41	Clamp to hold upright pipe to main frame	.90	.90
S 42	Washer	.10	.10
S 44	Complete section	2.45	3.00
S 45	Complete vane less pipe	6.00	9.00
S 48	Fairbury steel storm stay	1.50	1.50
ES 48	Storm stay for wood or steel tower	1.50	1.50
ES 49	Tower cap for wood or steel tower	1.50	1.50
S 50	Fairbury steel tower cap	1.50	1.50
S 50	Vane spring chain	.20	.20
S 51	Pitman box	.60	.60
S 53	Main shaft box	1.00	1.00
S 55	Crank and main shaft box	1.20	1.20
S 57	Crank shaft box	1.00	1.00
S 59	Storm stay for steel tower only	1.50	1.50
	1 complete set wood boxings	3.85	3.85
	Steel Blades for section	.60	.60
	Small wheel clips	.05	.05
	Large wheel clips	.10	.10
	1/4" Steel balls, each	.025	.025
	3/8"x1" Galv. Bolts	.04	.04