



1916 MODEL A-O AERMOTOR

The above shows the parts of the Auto-Oiled Aermotor of the 1916 Model. Repairs for the different sizes are designated by the letter "X" for 6-foot, "A" for 8-foot mill, "B" for 10-foot, "D" for 12-foot, "E" for 14-foot and "F" for 16-foot.





THE ³¹ AEROMOTOR
CHICAGO. ©.

314
314 1/2

232

44
45

46

47

35

536

34

100 1/2

639

578 579

557

558

510

554

625

555

614

665

672 1/2

661 1/2

604

605

627

626

628

667 1/2

609

604

695

694

668

675

674

243 1/2

556

614

613 1/2

622

506

375 1/2

513

82

690

50

686

376 377

645 646

38