


# Repairs for Eclipse Standard Windmill



Price List of Repairs for Eclipse Standard

Windmill-Parts.com Windmills Windmill-Parts.com

No.	Name	10-Foot A	12-Foot B	14-Foot C
1	Main Pivot Casting.....	\$ 8.40	\$10.50	\$21.00
2	Pivot Cap.....	1.05	1.30	2.40
3	Gate or Vane Hinge.....	3.15	4.30	7.15
4	Spider.....	3.70	4.20	5.25
4-1	Face Plate.....	1.60	2.10	3.15
4-2	Main Shaft.....	4.75	5.50	7.35
4-3	Brace Plate (new style).....	.45	.45	1.30
4-4	Brace Plate Cap (new style).....	.45	.45	.....
4-6	Brake.....	.45	.70	1.05
4-7	Brake Collar.....	.30	.45	.55
4-8	Brake Lever.....	.25	.25	.40
5	Outside-end Wheel Clip (Set).....	.75	1.00	1.95
6	Inside-end Wheel Clip (Set).....	.70	.90	1.75
7	Outside Wheel Clips (Set).....	.40	.45	1.05
8	Inside Wheel Clips (Set).....	.25	.40	.90
9	Truss Rod Clip.....	.40	.45	.75
9-1	Vane Bar Clip.....	.....	.....	.55
9-2	Vane Bar Clip.....	.25	.25	.55
10	Pitman.....	.55	.70	.75
11	Swivel Box }.....	1.05	1.30	1.60
11-1	Swivel Box Cap }.....	.....	.....	.....
12	Swivel.....	.55	.70	1.05
13	Governor Weight.....	2.10	3.00	4.75
14	Gate Gear.....	.55	.70	1.60
15	Upper Piston Guide.....	3.15	3.40	4.20
15-1	Upper piston Guide Cap.....	.....	.....	.....
15-2	Upper Piston Guide Washer.....	.15	.15	.45
16	Lower Guide.....	.45	.55	1.00
17	Tower Cap.....	1.05	1.45	2.10
18	Pivot Step.....	1.30	1.60	3.15
19	Weight Arm Gear.....	.90	1.30	2.55
20	Chain Sheave.....	.25	.25	.40
21	Link.....	.25	.25	.40
22	Sheave cover (old style).....	.25	.25	.40
23	Gear Cover.....	.40	.55	.90
24	Piston Rod.....	1.60	2.10	3.70
25	Pullout Rod.....	.45	.45	.55
26	Weight Arm.....	1.05	2.10	3.15
27	Rudder Vane Bar.....	3.15	4.75	8.40
28	Truss Rod.....	.55	.75	2.10
29	Side Vane Bar.....	1.60	2.60	4.20
30	Stud Pin.....	.60	.60	.70
31	Wrist Pin.....	.60	.75	.90
32	Pullout Chain.....	.45	.70	.90
38	Wheel Front Braces (set).....	2.00	2.55	3.40
33	Counterpoise.....	.75	.75	1.30
34	Pump Connection.....	.55	.75	1.05
	Side Vane Staple.....	.25	.25	.40
	Rubber Bumper.....	.40	.55	1.00
	Pump Pole Splice Irons (pair).....	.40	.40	.45
	Splice Iron Bolts (four).....	.25	.25	.25
	Pump Connection Bolts (two).....	.15	.15	.20
	Swivel Box Bolts (two).....	.15	.15	.20
	Lever Bolt.....	.10	.12	.12
	Wheel Bolts (set).....	.90	1.30	1.75
	Pullout Wire.....	.55	.55	.60
	Tower Rods (four).....	.45	.45	.70
	Tower Blocks (four).....	.25	.40	.55
	Pullout Lever.....	.60	.60	1.60
	Pump Poles (pair).....	1.30	1.25	1.70
	Rudder Vane.....	4.75	7.35	12.60
	Side Vane.....	.75	1.05	2.10
	Wheel Arms (set).....	2.10	3.40	6.75
	Wheel Sections (set).....	12.60	16.80	33.60
	Wheel Slats (each).....	.15	.15	.18
	Outside Girts (each).....	.25	.30	.52
	Inside Girts (each).....	.20	.21	.25

When ordering repairs be careful to note the letter preceding the number of part which indicates the size of mill. To correctly fill orders for the Eclipse Standard Windmills we must have the following information: Diameter or size of wind-wheel, number and letter on casting, and year mill was purchased. In ordering repairs for Eclipse mills, state whether the mill has long or short stroke, and when ordering Pivot No. 1 or Weight Arm Gear No. 19, give size of pin cast in back of pivot. Delay and annoyance can be avoided by giving us the foregoing information with your order, otherwise we shall be obliged to write for it in many cases. Repairs for old style 8 1/2-foot Eclipse can be had at same price as for 10-foot. Terms on all repairs strictly cash, and they will be sent C. O. D. unless cash accompanies the order.