


REPAIRS FOR NO. 1 VANELESS MILL

Windmill-Parts.com

940 597-7735

Windmill-Parts.com

940 597-7735



Windmill-Parts.com

940 597-7735

Windmill-Parts.com

940 597-7735

Windmill-Parts.com

940 597-7735

PART NO.	NAME	10 Ft. No. 1	12 Ft. No. 1	PART NO.	NAME	10 Ft. No. 1	12 Ft. No. 1
No. 1	Main frame	\$4.65	\$5.85	No. 27	R & L fan castings, each	.30	.35
No. 2	Upright	4.65	5.85	No. 28	Right and left shifting castings, each	.60	.70
No. 3	Tower Casting	2.30	2.90	No. 29	Crank, pin and nut	.90	.95
No. 4	Crank Plate	1.85	2.05	No. 30	Governor weight	1.50	1.50
No. 5	Spider	4.65	5.85	No. 31	Set collar	.40	.45
No. 6	Step	1.15	1.25	No. 32	Arm castings, each	.30	.40
No. 7	Lower half ball	1.25	1.40	No. 33	Slide head strap, bottom	.70	.35
No. 8	Top half ball	1.25	1.40	No. 34	Slide head strap, top	.60	.70
No. 9	Pitman	1.75	1.85	No. 35	Clip	.25	.25
No. 10	Swivel	.95	1.05	No. 36	Swivel clip	.25	.30
No. 11	Wood rod connection	.45	.50	No. 37	Pump connection	.60	.60
No. 12	Umbrella spider	.95	1.05	No. 38	Clamp casting	.25	.25
No. 13	Lower half of box	.95	1.15	UN-NUMBERED PARTS			
No. 14	Top half of box	.85	1.05	Wood arms, painted, each	.85	.90	
No. 15	Female half of slide head	.35	.45	Wood wheel sections, each	3.60	3.60	
No. 16	Male half of slide head	.35	.45	Wood slats, each	.12	.12	
No. 17	Section casting	.70	.70	Wood long section cross bar	.60	.60	
No. 18	Clip on step	.20	.25	Wood short section cross bar	.45	.45	
No. 19	Fan rods, each	.30	.35	Wood balance weight bar	1.00	1.00	
No. 20	Umbrella rods, each	.35	.40	Wood truss, upright	.55	.55	
No. 21	Twin rods, each	.30	.30	Wood pump rod, per 100 ft.	4.40	4.40	
No. 22	Shifting bar, complete	2.70	2.90	Long iron truss rods, each	.45	.45	
No. 23	Large wood box, 2 pieces	1.25	1.40	Short iron truss rods, each	.45	.45	
No. 24	Shield	.60	.70	Wood pull-out lever	.60	.65	
No. 25	Pitman box	.30	.35	Bull	2.30	2.30	
No. 26	Splice irons, 2 pieces	.45	.45	Plate	1.75	1.75	