


## Repair Parts

MODEL 28, 8-FOOT AND 10-FOOT DIRECT STROKE BAKER  
RUN-IN-OIL WINDMILL

Windmill-Parts.com 940 597-7735

Windmill-Parts.com 940 597-7735



IMPORTANT—ALWAYS GIVE MODEL NUMBER APPEARING ON  
OIL BOWL TOGETHER WITH NUMBER AND DESCRIPTION  
OF PART WANTED, WHEN ORDERING REPAIRS.

Windmill-Parts.com  
940 597-7735

# Repair Parts List

MODEL 28—8, 10-FOOT DIRECT STROKE BAKER MILLS

Symbol No.	Article	8-Foot Mill		10-Foot Mill	
		Part No.	List Price	Part No.	List Price
0	Galvanized Hood.....	.....	\$2.00	.....	\$2.00
1	Governor Spring.....	.....	1.40	.....	1.50
2	Eccentric, complete.....	.....	4.00	.....	4.00
.....	Lower Part of Eccentric with Shank and Pin Bearing.....	.....	1.50	.....	1.50
.....	Upper Part Eccentric Ring.....	.....	1.50	.....	1.50
.....	Cam only for Eccentric.....	.....	1.00	.....	1.00
3	Rocker Arm.....	OE	3.00	OE	3.00
4	Truing Center.....	XII	1.25	XII	1.25
5	Vane Casting.....	BB8	2.50	BB10	3.50
6	Wheel Hub.....	VIIIIH	3.00	XH	3.50
7	Side Arms for Pump Rod Hitch, each.....	.....	.80	.....	.80
8	Top Casting for Pump Rod Hitch.....	SSS	1.00	SSS	1.00
9	Main Removable Bearing, complete.....	77	3.00	77	3.00
10	Cast Pulley for Chain, each.....	.....	.30	.....	.30
11	Ball Bearing Turntable, complete.....	X1213	2.25	X1213	2.25
12	Pin Holding Rocker Arm to Bowl.....	.....	.50	.....	.50
13	Pin for Rocker Arm and Eccentric.....	.....	.50	.....	.50
14	Taper Steel Pin and Nut for Hub.....	.....	.20	.....	.20
15	Cast Collar for Shaft.....	.....	.50	.....	.50
16	Main Shaft.....	.....	2.00	.....	2.50
17	Pull Out Chain.....	.....	.50	.....	.50
18	Steel Pump Rod and Swivel.....	.....	4.50	.....	4.50
19	Steel Pull Out Rod.....	.....	.50	.....	.50
0	Oil Rings, each.....	.....	.15	.....	.15
Mod.	Oil Bowl, with Pipe Stem.....	.....	11.00	.....	11.00
.....	Pin for Vane Casting.....	.....	.50	.....	.50
.....	Gland only for Main Bearing.....	.....	.50	.....	.50
.....	Short Rim for Wheel.....	.....	1.40	.....	1.50
.....	Long Rim for Wheel.....	.....	1.50	.....	2.00
.....	Small Steel Chair.....	.....	.10	.....	.10
.....	Large Steel Chair.....	.....	.15	.....	.15
.....	Wheel Fan or Blade.....	.....	.25	.....	.25
.....	Flat Steel Wheel Arm.....	.....	.80	.....	1.00
.....	Angle Steel Wheel Brace.....	.....	.50	.....	.60
.....	Vane Stem or Pipe.....	.....	2.30	.....	3.00
.....	Supporting Rod for Vane.....	.....	.90	.....	1.00
.....	Wheel Section, complete.....	.....	3.50	.....	4.00
.....	Complete Wheel (6 sections) with Bolts, Wheel Arms and Braces.....	.....	25.00	.....	28.00
.....	Engine, complete.....	.....	23.50	.....	27.00
.....	Set of 26 Balls for Turntable.....	.....	.70	.....	.70
.....	Set of Mill Bolts (19 double nutted, 47 single nutted).....	.....	1.80	.....	1.80
.....	Set of Wheel Bolts (19 double nutted, 13 single nutted).....	.....	1.00	.....	1.00
.....	Vane complete.....	.....	9.50	.....	11.00
.....	Baker Zero Oil.....	½ gal.	.65	½ gal.	.65

## REPAIR PARTS LIST FOR DIRECT STROKE RUN-IN-OIL ENGINE With Babbitt Eccentric and Oiling Gears (Discontinued)

Article	8-Foot Mill		10-Foot Mill	
	Part No.	List Price	Part No.	List Price
Oil Bowl.....	003	\$9.00	003	\$9.00
Main Casting, with Pipe.....	05	8.00	05	8.00
Babbitted Eccentric complete, (Interchangeable with H-2 Eccentric).....	00H2	3.50	00H2	3.50
Rocker Arm.....	00T	2.00	00T	2.00
Stand for Rocker Arm.....	002	1.50	002	1.50
Oil Finger.....	N00	.50	N00	.50
Hub for Wheel.....	VIIIIH	3.00	XH	3.50
Vane Casting.....	F2	2.50	W20	3.50
Cast Pump Rod Hitch.....	OSO	.80	OSO	.80
Small Upper Oil Carryin. Gear.....	X00	1.00	X00	1.00
Large Oil Carrying Gear.....	.....	1.75	.....	1.75
Cam only for Eccentric.....	.....	1.00	.....	1.00
Galvanized Cap for Bowl.....	.....	1.75	.....	1.75
Steel Pump Rod and Swivel.....	.....	4.50	.....	4.50
Ell Shaped Wrought Iron Oil Gear Guide.....	.....	1.50	.....	1.50

Other parts duplicates of Model 28 Windmill.

GIVE SIZE AND MODEL NUMBER OF MILL, ALSO PART AND DESCRIPTION OF ARTICLE WHEN ORDERING