


Repair Parts

Windmill-Parts.com
940 597-7735

Windmill-Parts.com
940 597-7735



Windmill-Parts.com

Windmill-Parts.com

IMPORTANT—ALWAYS GIVE MODEL NUMBER APPEARING ON OIL BOWL TOGETHER WITH NUMBER AND DESCRIPTION OF PART WANTED WHEN ORDERING REPAIRS.

Windmill-Parts.com
940 597-7735

Repair Parts

Windmill-Parts MODELS 8, 10, 12 BAKER BACK GEARED MILLS

940 597-7735 The Model Number Designates the Size of the Windmill 940 597-7735

Symbol Number	Article	8-Ft. Mill		10-Foot Mill		12-Foot Mill	
		Part No.	List Price	Part No.	List Price	Part No.	List Price
0	Galvanized Hood.....	80	\$ 2.00	100	\$ 2.50	120	\$ 3.00
1	Large Gear Wheel.....	81	2.50	10A	2.70	121	3.20
2	Pump Rod Side Arm Hitch, each..	82	.80	102	.90	122	1.20
3	Steel Pin for Pitman and Rocker Arm.....	83	.50	103	.50	123	.50
4	Cast Pitman.....	84	1.50	10D	1.70	124	2.00
5	Vane Casting.....	85	2.50	10T	3.50	125	4.50
6	Wheel Hub.....	86	3.00	106	3.50	126	4.20
7	Small Gear, each.....	87	.90	107	1.10	127	1.40
8	Rocker Arm.....	88	2.80	10H	3.00	128	3.50
9	Removable Main Bearing.....	8	3.00	5	3.20	2	3.50
10	Main Shaft.....	810	2.00	1010	2.50	1210	3.00
11	Bumper Springs, each.....	811	.20	1011	.20	1211	.20
12	Crank Pins for Large Gears, each	812	.50	1012	.50	1212	.50
13	Cast Pulley for Chain, each.....	813	.30	1013	.30	1213	.30
14	Pin for Pitman and Large Gears, each.....	814	.50	1014	.50	1214	.50
15	Pin Holding Rocker Arm to Oil Bowl.....	815	.50	1015	.50	1215	.50
16	Governor Spring.....	816	1.40	1016	1.50	1216	2.00
17	Pin for Vane Casting.....	817	.50	1017	.50	1217	.50
18	Steel Pump Rod and Swivel.....	818	4.50	1018	4.50	1218	6.00
19	Steel Pull Out Rod.....	819	.50	1019	.50	1219	.50
20	Pull Out Chain.....	820	.50	1020	.50	1220	.50
21	Hub Taper Steel Pin and Nut.....	821	.20	1021	.20	1221	.30
Mod.	Oil Bowl and Pipe Stem.....	Mod. 8	11.00	Mod. 10	13.50	Mod. 12	20.00
TT	Ball Bearing Turntable.....	X1213	2.25	X1213	2.25	TT12	3.00
TC	Truing Center.....	X11	1.25	X11	1.25	TC12	2.00
SSS	Pump Rod Hitch.....	SSS	1.00	SSS	1.00	SSS	1.40
.....	Short Wheel Rim with Chairs.....	1.10	1.50	3.00
.....	Long Wheel Rim with Chairs.....	1.50	2.00	4.20
.....	Small Chair for Sail.....101520
.....	Large Chair for Sail.....152030
.....	Gland complete for Stuffing Box.....505070
.....	Wheel Fan or Sail.....254060
.....	Flat Steel Wheel Arm.....80	1.00	1.50
.....	Angle Steel Wheel Brace.....5060	1.00
.....	Vane Stem or Pipe.....	2.30	3.00	4.00
.....	Supporting Rod for Vane.....90	1.00	1.50
.....	*Wheel Section complete.....	3.50	4.00	6.00
.....	Wheel complete with Arms, Braces and Bolts.....	25.00	28.00	52.00
.....	Vane complete.....	9.50	11.00	20.00
.....	Engine complete.....	23.50	27.00	48.50
.....	Set of Mill Bolts.....	1.80	1.80	2.20
.....	Wood Rod Splices with Bolts.....505050
.....	Set of Wheel Bolts.....	1.00	1.00	1.40
.....	Baker Zero Oil.....	1/2 gal.	.65	3/4 gal.	.90	1 gal.	1.10

*Model 8 has six sections with six blades to a section. Model 10 has six sections with five blades to a section. Model 12 has eight sections with four blades to a section.

Windmill-Parts.com

940 597-7735