


REPAIR LIST FOR MONITOR SELF-OILING WINDMILLS, PULL-IN-TYPE



Give Both Name and Symbol of Each Part

Symbol	Name of Parts for "AC" Windmill	Weight		Price Each
		Lb.	Oz.	
WC1	Upper tower casting	2	3	\$ 2.45
WC2	Lower tower casting	6	8	2.90
WC4	Sheave shield - assembly	2	5	6.60
AC5	Ball bearing cup	2	11	1.75
WC6*	Wheel shaft bushing - long	0	5	.65
WC6½*	Wheel shaft bushing - short	0	3	.45
AC7A	Pitman guide.	5	5	5.25
AC8A	Crank gear.	12		7.70
AC9	Pinion	2	8	3.30
AC10	Wheel hub & shaft	20		10.60
WC11	Upper vane hinge.	1	5	1.10
WC12	Lower vane hinge	4	5	2.15
AC13	Latch.		10	.70

Symbol	Name of Parts	Weight		Price Each
		Lb.	Oz.	
WC14*	Sheave		10	\$.75
AC15	Brake.	7	11	
WC16	Piston eye	1	8	2.90
WC17*	Upper pump pole casting	1	4	1.40
WC18*	Inner swivel		8	.95
WC19	Outer swivel	2	2	1.90
AC21	Crank case cover.	6	10	
AC42	Oil ring assembly 735		11	3.85
AC43	Oil ring only		2	
AC46	Oil trough		3	.50
AC47	Oil spout		2	
AC51	Crank gear shaft - threaded	1	13	
WC52	Pitman guide hinge pin		11	1.10
AC53A	Pitman	3		2.90
WC54	Piston rod	4		2.00
AC55	Vane hinge pin	1	5	.70
AC56	Brake rod		11	1.05
WC58*	Sheave pin		2	.25
WC60	Latch pitman.		10	.65
E63	Vane stem	10	8	3.50
AC64	Vane truss	5		
E65	Vane rib - short		13	
E67	Vane rib - long	1	6	
WC68*	Wheel spoke	3	13	3.00
E69	Outer rim (6 Sec.)	2	5	1.20
E70	Inner rim (6 Sec.)		14	.80
WC71*	Sail with clips	3		1.40
AC72	Vane sheet - upper	5	8	
AC73	Vane sheet - lower	5		
WC74*	Sail clip - large 940 597-7735		4	.25
WC75*	Sail clip - small		2	.15
WC76	Oil collar.		1	.25
WC78	Chain extension		5	.25
AC79A	Swivel bail.	3		1.40
WC80	Chain end	1	4	.25
AC81	Step bearing cone		11	1.40
WC82*	Governor spring	2	12	1.90
WC83	Brake spring.		4	.35
AC85	Swivel chain (3/16 x 28-3/4" long) with WC-78	1	2	2.00
WC120	Pump coupler assembly	2		1.60
WC88	Spring for pump coupler		2	.35
K501-1	Wheel section	12		6.50

*Current WC parts.

Windmill-Parts.com
940 597-7735

Windmill-Parts.com
940 597-7735

Windmill-Parts.com
940 597-7735