


REPAIR PARTS FOR "E" AND "X" STYLE STEEL MILLS

Windmill-Parts.com
940 597-7735



Windmill-Parts.com
940 597-7735

Windmill-Parts.com
940 597-7735

Windmill-Parts.com
940 597-7735

REPAIR LIST FOR MONITOR STEEL WINDMILLS

Windmill-Parts.com
940 597-7735

Name of Part	8-foot E Style		10-foot X Style			
	Symbol	Price	Weight	Symbol	Price	Weight
Upper tower casting -----	E1	\$0.20	1.9	E1	.20	1.9
Lower tower casting -----	E2	.40	3.6	E2	.40	3.6
Swivel stop -----	E2½	.30	1.7	E2½	.30	1.7
Main casting with bushings -----	E3	7.00	37	X3	10.00	56
Sheave shield -----	E4	.50	2.8	X4	.60	3.4
Sheave shield with sheave -----		.80	3.5		.90	
Bushing for crank gear -----	E5	.40	.2	X5	.80	.4
Bushing for main casting -----	E6	.20	.2	X6	.30	.4
Pitman guide -----	E7	.50	2.5	X7	.70	5
Crank gear with shaft and bushing -----	K8	3.00	14	X8	4.50	25
Pinion -----	E9	.70	3.3	X9	1.00	6
Wheel spider with shaft -----	E10	3.00	17	X10	4.50	22
Brace spider -----				X10½	.70	3
Vane hinge, upper -----	E11	.20	.8	X11	.20	1.3
Vane hinge, lower -----	E12	.60	3.9	X12	.80	6
Latch -----	E13	.20	1	E13	.20	1
Sheave -----	E14	.20	.6	E14	.20	.6
Brake -----	E15	.50	3.1	X15	.80	6
Brake, with rod and spring -----		.90	4		1.40	7
Piston eye -----	E16	.50	1.5	X16	.60	2
Pump-pole socket -----	E17	.20	1.1	X17	.30	1.7
Swivel slide with washers -----	E18	.40	1.1	E18	.40	1.1
Swivel eye -----	E19	.20	.3	E19	.20	.3
Pump attachment -----	K20	.60	2.3	K20	.60	2.3
Grease plunger -----	E21	.10	.2	E21	.10	.2
Pipe collar -----	E22	.20	.9	E22	.20	.9
Grease cup ratchet -----	E23	.20		E23	.30	.3
Grease cup, plain -----	E24	.20		E24	.20	
Pitman guide pin -----	E52	.10	.3	X52	.20	.4
Pitman -----	E53	.80	3.8	X53	1.20	6
Piston rod with nut only -----	E54	.60	3.5	X54	.70	5.5
Piston, with pump-pole socket -----		.80	5		1.00	7.6
Vane pin -----	E55	.20	.9	X55	.30	1.8
Brake rod -----	E56	.20	.6	X56	.30	.7
Sheave pin -----	E59	.10	.1	E59	.10	.1
Latch pitman -----	E60	.20	.3	E60	.20	.3
Vane stem -----	E63	2.00	10.5	X63	4.00	19
Vane truss -----	E64	1.00	5	X64	1.60	8
Vane rib, short -----	E65	.20	.8	X65	.40	1.6
Vane rib, medium -----	E66	.30	1.1	X66	.50	2.2
Vane rib, long -----	E67	.40	1.4	X67	.60	2.8
Arms, each -----	E68	.80	3.8	X68	1.30	5.1
Outer rim -----	E69	.50	2.3	X69	1.00	5
Inner rim -----	E70	.20	.8	X70	.40	1.4
One sail, with clips -----		1.00	3		1.50	5.2
Sail clip, large -----	E74	.10	.2	X74	.20	.4
Sail clip, small -----	E75	.10	.1	X75	.10	.2
Governor spring -----	E82	1.00	5	X82	1.50	7
Brake spring -----	E83	.10	.2	X83	.20	.2
Latch spring -----	E84	.10	.1	E84	.10	.1
Chain with extension -----	E85	.60	1.2	E85	.60	1.2
Completed Parts						
One section for wheel -----		3.50	13		6.00	23
Pull-in lever, complete -----		.80	1.5		1.00	1.5